


HVLP Gravity Feed Spray Gun

Replacement Parts List



No.	Description	qty
1.	Air Cap (100% spray pattern test)	1
2.	Air Cap Retainer	1
3.	Air Cap Retainer Ring	1
4.	Fluid Tip	1
5.	Baffle	1
6.	Plastic Diffuser	1
7.	Needle Packing Nut	1
8.	Needle Packing	1
9.	Packing Washer	1
10.	Packing Spring	1
11.	Gun Body	1
12.	Fluid Needle	1
13.	Needle Spring Ø1.0x62mm	1
14.	Fluid Adjust Seat	1
15.	Fluid Adjust Knob	1
16.	Pattern Adjust Knob Screw	1
17.	Pattern Adjust Knob	1
18.	Pattern Adjust Valve Gasket	1
19.	Pattern Adjust Valve	1
20.	Pattern Adjust Seat	1
21.	Pattern Adjust Seat Washer	1
22.	E-Ring (E4)	1
23.	Trigger Stud	1
24.	Trigger Spacer	2
25.	Trigger	1
26.	E-Ring (E5)	2
27.	Trigger Stud W/Needle Hole	1
28.	Fluid Inlet	1
29.	Fluid Filter	1
30.	Fluid Cup	1
31.	Throttle Valve Cap Nut (assembly)	1
32.	Throttle Valve O-ring (Viton)	1
33.	Throttle Valve Seat	1
34.	Throttle Valve Seat Gasket	1
35.	Throttle Valve	1
36.	Throttle Valve Spring, Ø0.8x31mm	1
37.	Air Inlet Fitting	1
38.	Air Regulator Turning Knob	1
39.	O-Ring	1
40.	Air Regulator Bushing	1
41.	E-Ring (E4)	1
42.	Air Regulator Valve	1
43.	Wrench	1
44.	Filter in-line	1